

## PRODUCT-DETAILS

# 3ADT751007P0001

PWS XXX FOR D7 4000:1 / 5KA; CURRENT TRANSFORMER 5kA, 4000



## General Information

|                      |                                                            |
|----------------------|------------------------------------------------------------|
| Product ID           | 3ADT751007P0001                                            |
| ABB Type Designation | PWS XXX FOR D7 4000:1 / 5KA                                |
| Catalog Description  | PWS XXX FOR D7 4000:1 / 5KA; CURRENT TRANSFORMER 5kA, 4000 |
| Long Description     | CURRENT TRANSFORMER,5000A                                  |

## Ordering

|                              |                 |
|------------------------------|-----------------|
| Customs Tariff Number        | 85043129        |
| Replacement Product ID (NEW) | 3ADT751007P0003 |
| Quote Only                   | No              |
| Made To Order                | No              |
| Part Type                    | New             |
| Selling Unit of Measure      | piece           |
| Minimum Order Quantity       | 1 piece         |
| Order Multiple               | 1 piece         |

## Dimensions

|                    |        |
|--------------------|--------|
| Product Net Weight | 6.5 kg |
|--------------------|--------|

## Technical

Technical Information

CURRENT TRANSFORMER 5kA, 4000 : 1 /PWS XXX FOR D7 4000:1

Temperature Class

--

Default

Two Speed Motor

No

## Additional Information

Product Name

CURRENT TRANSFORMER 5kA, 4000

## Where Used (as a spare part for "Products")

| Identifier       | Description              | Quantity | Unit Of Measure |
|------------------|--------------------------|----------|-----------------|
| DCS601-2050-61-R | No Description Available | 1        | piece           |
| DCS601-2050-61-R | No Description Available | 1        | piece           |
| DCS601-2050-61-L | No Description Available | 1        | piece           |
| DCS601-2050-61-L | No Description Available | 1        | piece           |
| DCS601-2050-71-R | No Description Available | 1        | piece           |
| DCS601-2050-71-R | No Description Available | 1        | piece           |
| DCS601-2050-71-L | No Description Available | 1        | piece           |
| DCS601-2050-71-L | No Description Available | 1        | piece           |
| DCS601-2050-81-R | No Description Available | 1        | piece           |
| DCS601-2050-81-R | No Description Available | 1        | piece           |
| DCS601-2050-81-L | No Description Available | 1        | piece           |
| DCS601-2050-81-L | No Description Available | 1        | piece           |
| DCS601-2053-91-L | No Description Available | 1        | piece           |
| DCS601-2050-91-L | No Description Available | 1        | piece           |
| DCS601-2050-91-L | No Description Available | 1        | piece           |
| DCS601-2053-91-R | No Description Available | 1        | piece           |
| DCS601-2050-91-R | No Description Available | 1        | piece           |
| DCS601-2050-91-R | No Description Available | 1        | piece           |
| DCS601-2500-41-R | No Description Available | 1        | piece           |
| DCS601-2500-41-R | No Description Available | 1        | piece           |
| DCS601-2500-41-L | No Description Available | 1        | piece           |
| DCS601-2500-41-L | No Description Available | 1        | piece           |
| DCS601-2500-51-R | No Description Available | 1        | piece           |
| DCS601-2500-51-R | No Description Available | 1        | piece           |
| DCS601-2500-51-L | No Description Available | 1        | piece           |
| DCS601-2500-51-L | No Description Available | 1        | piece           |
| DCS601-2500-61-R | No Description Available | 1        | piece           |
| DCS601-2500-61-R | No Description Available | 1        | piece           |
| DCS601-2500-61-L | No Description Available | 1        | piece           |
| DCS601-2500-61-L | No Description Available | 1        | piece           |
| DCS601-2500-71-R | No Description Available | 1        | piece           |
| DCS601-2500-71-R | No Description Available | 1        | piece           |
| DCS601-2500-71-L | No Description Available | 1        | piece           |
| DCS601-2500-71-L | No Description Available | 1        | piece           |
| DCS601-2603-91-L | No Description Available | 1        | piece           |
| DCS601-2650-91-L | No Description Available | 1        | piece           |
| DCS601-2650-91-L | No Description Available | 1        | piece           |
| DCS601-2603-91-R | No Description Available | 1        | piece           |
| DCS601-2650-91-R | No Description Available | 1        | piece           |
| DCS601-2650-91-R | No Description Available | 1        | piece           |

[illegible]

[illegible]

[illegible]

[illegible]

[illegible]

[illegible]

|                  |                          |   |       |
|------------------|--------------------------|---|-------|
| DCS501B4803-71-L | No Description Available | 1 | piece |
| DCS501B4750-71-L | No Description Available | 1 | piece |
| DCS501B4803-71-R | No Description Available | 1 | piece |
| DCS501B4750-71-R | No Description Available | 1 | piece |
| DCS501B4803-81-L | No Description Available | 1 | piece |
| DCS501B4750-81-L | No Description Available | 1 | piece |
| DCS501B4803-81-R | No Description Available | 1 | piece |
| DCS501B4750-81-R | No Description Available | 1 | piece |
| DCS501B5203-41-L | No Description Available | 1 | piece |
| DCS501B5150-41-L | No Description Available | 1 | piece |
| DCS501B5203-41-R | No Description Available | 1 | piece |
| DCS501B5150-41-R | No Description Available | 1 | piece |
| DCS501B5203-51-L | No Description Available | 1 | piece |
| DCS501B5150-51-L | No Description Available | 1 | piece |
| DCS501B5203-51-R | No Description Available | 1 | piece |
| DCS501B5150-51-R | No Description Available | 1 | piece |
| DCS501B2603-11-L | No Description Available | 1 | piece |
| DCS501B2650-11-L | No Description Available | 1 | piece |
| DCS501B2603-11-R | No Description Available | 1 | piece |
| DCS501B2650-11-R | No Description Available | 1 | piece |
| DCS501B3303-11-L | No Description Available | 1 | piece |
| DCS501B3200-11-L | No Description Available | 1 | piece |
| DCS501B3303-11-R | No Description Available | 1 | piece |
| DCS501B3200-11-R | No Description Available | 1 | piece |
| DCS502B2050-61-R | No Description Available | 1 | piece |
| DCS502B2050-61-L | No Description Available | 1 | piece |
| DCS502B2050-71-R | No Description Available | 1 | piece |
| DCS502B2050-71-L | No Description Available | 1 | piece |
| DCS502B2050-81-R | No Description Available | 1 | piece |
| DCS502B2050-81-L | No Description Available | 1 | piece |
| DCS502B2053-91-L | No Description Available | 1 | piece |
| DCS502B2050-91-L | No Description Available | 1 | piece |
| DCS502B2053-91-R | No Description Available | 1 | piece |
| DCS502B2050-91-R | No Description Available | 1 | piece |
| DCS502B2500-41-R | No Description Available | 1 | piece |
| DCS502B2500-41-L | No Description Available | 1 | piece |
| DCS502B2500-51-R | No Description Available | 1 | piece |
| DCS502B2500-51-L | No Description Available | 1 | piece |
| DCS502B2500-61-R | No Description Available | 1 | piece |
| DCS502B2500-61-L | No Description Available | 1 | piece |
| DCS502B2500-71-R | No Description Available | 1 | piece |
| DCS502B2500-71-L | No Description Available | 1 | piece |
| DCS502B2603-91-L | No Description Available | 1 | piece |
| DCS502B2650-91-L | No Description Available | 1 | piece |
| DCS502B2603-91-R | No Description Available | 1 | piece |
| DCS502B2650-91-R | No Description Available | 1 | piece |
| DCS502B3200-81-R | No Description Available | 1 | piece |
| DCS502B3200-81-L | No Description Available | 1 | piece |
| DCS502B3200-91-R | No Description Available | 1 | piece |
| DCS502B3200-91-L | No Description Available | 1 | piece |
| DCS502B3303-41-L | No Description Available | 1 | piece |
| DCS502B3300-41-L | No Description Available | 1 | piece |
| DCS502B3303-41-R | No Description Available | 1 | piece |
| DCS502B3300-41-R | No Description Available | 1 | piece |
| DCS502B3303-51-L | No Description Available | 1 | piece |
| DCS502B3300-51-L | No Description Available | 1 | piece |
| DCS502B3303-51-R | No Description Available | 1 | piece |





[illegible]



| Product          | Category          | Drive Part Category                          |
|------------------|-------------------|----------------------------------------------|
| DCS601-2050-61-R | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-2050-61-R | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-2050-61-L | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-2050-61-L | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-2050-71-R | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-2050-71-R | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-2050-71-L | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-2050-71-L | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-2050-81-R | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-2050-81-R | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-2050-81-L | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-2050-81-L | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-2053-91-L |                   | Transformers, Transducers (Voltage, Current) |
| DCS601-2050-91-L | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-2050-91-L | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-2053-91-R |                   | Transformers, Transducers (Voltage, Current) |
| DCS601-2050-91-R | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-2050-91-R | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-2500-41-R | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-2500-41-R | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-2500-41-L | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-2500-41-L | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-2500-51-R | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-2500-51-R | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-2500-51-L | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-2500-51-L | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-2500-61-R | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-2500-61-R | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-2500-61-L | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-2500-61-L | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-2500-71-R | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-2500-71-R | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |

| Product          | Category          | Drive Part Category                          |
|------------------|-------------------|----------------------------------------------|
| DCS601-2500-71-L | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-2500-71-L | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-2603-91-L |                   | Transformers, Transducers (Voltage, Current) |
| DCS601-2650-91-L | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-2650-91-L | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-2603-91-R |                   | Transformers, Transducers (Voltage, Current) |
| DCS601-2650-91-R | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-2650-91-R | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-3200-81-R | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-3200-81-R | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-3200-81-L | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-3200-81-L | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-3200-91-R | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-3200-91-R | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-3200-91-L | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-3200-91-L | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-3303-41-L |                   | Transformers, Transducers (Voltage, Current) |
| DCS601-3300-41-L | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-3300-41-L | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-3303-41-R |                   | Transformers, Transducers (Voltage, Current) |
| DCS601-3300-41-R | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-3300-41-R | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-3303-51-L |                   | Transformers, Transducers (Voltage, Current) |
| DCS601-3300-51-L | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-3300-51-L | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-3303-51-R |                   | Transformers, Transducers (Voltage, Current) |
| DCS601-3300-51-R | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-3300-51-R | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-3303-61-L |                   | Transformers, Transducers (Voltage, Current) |
| DCS601-3300-61-L | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-3300-61-L | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-3303-61-R |                   | Transformers, Transducers (Voltage, Current) |

| Product          | Category          | Drive Part Category                          |
|------------------|-------------------|----------------------------------------------|
| DCS601-3300-61-R | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-3300-61-R | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-3303-71-L |                   | Transformers, Transducers (Voltage, Current) |
| DCS601-3300-71-L | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-3300-71-L | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-3303-71-R |                   | Transformers, Transducers (Voltage, Current) |
| DCS601-3300-71-R | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-3300-71-R | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-3303-81-L |                   | Transformers, Transducers (Voltage, Current) |
| DCS601-3303-81-R |                   | Transformers, Transducers (Voltage, Current) |
| DCS601-3303-91-L |                   | Transformers, Transducers (Voltage, Current) |
| DCS601-3303-91-R |                   | Transformers, Transducers (Voltage, Current) |
| DCS601-4003-41-L |                   | Transformers, Transducers (Voltage, Current) |
| DCS601-4000-41-L | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-4000-41-L | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-4003-41-R |                   | Transformers, Transducers (Voltage, Current) |
| DCS601-4000-41-R | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-4000-41-R | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-4003-51-L |                   | Transformers, Transducers (Voltage, Current) |
| DCS601-4000-51-L | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-4000-51-L | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-4003-51-R |                   | Transformers, Transducers (Voltage, Current) |
| DCS601-4000-51-R | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-4000-51-R | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-4003-61-L |                   | Transformers, Transducers (Voltage, Current) |
| DCS601-4000-61-L | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-4000-61-L | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-4003-61-R |                   | Transformers, Transducers (Voltage, Current) |
| DCS601-4000-61-R | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-4000-61-R | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-4003-71-L |                   | Transformers, Transducers (Voltage, Current) |
| DCS601-4000-71-L | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |

| Product          | Category          | Drive Part Category                          |
|------------------|-------------------|----------------------------------------------|
| DCS601-4000-71-L | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-4003-71-R |                   | Transformers, Transducers (Voltage, Current) |
| DCS601-4000-71-R | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-4000-71-R | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-4003-81-L |                   | Transformers, Transducers (Voltage, Current) |
| DCS601-4000-81-L | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-4000-81-L | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-4003-81-R |                   | Transformers, Transducers (Voltage, Current) |
| DCS601-4000-81-R | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-4000-81-R | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-4003-91-L |                   | Transformers, Transducers (Voltage, Current) |
| DCS601-4000-91-L | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-4000-91-L | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-4003-91-R |                   | Transformers, Transducers (Voltage, Current) |
| DCS601-4000-91-R | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-4000-91-R | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-4803-61-L |                   | Transformers, Transducers (Voltage, Current) |
| DCS601-4750-61-L | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-4750-61-L | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-4803-61-R |                   | Transformers, Transducers (Voltage, Current) |
| DCS601-4750-61-R | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-4750-61-R | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-4803-71-L |                   | Transformers, Transducers (Voltage, Current) |
| DCS601-4750-71-L | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-4750-71-L | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-4803-71-R |                   | Transformers, Transducers (Voltage, Current) |
| DCS601-4750-71-R | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-4750-71-R | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-4803-81-L |                   | Transformers, Transducers (Voltage, Current) |
| DCS601-4750-81-L | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-4750-81-L | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-4803-81-R |                   | Transformers, Transducers (Voltage, Current) |

| Product          | Category          | Drive Part Category                          |
|------------------|-------------------|----------------------------------------------|
| DCS601-4750-81-R | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-4750-81-R | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-5203-41-L |                   | Transformers, Transducers (Voltage, Current) |
| DCS601-5150-41-L | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-5150-41-L | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-5203-41-R |                   | Transformers, Transducers (Voltage, Current) |
| DCS601-5150-41-R | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-5150-41-R | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-5203-51-L |                   | Transformers, Transducers (Voltage, Current) |
| DCS601-5150-51-L | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-5150-51-L | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-5203-51-R |                   | Transformers, Transducers (Voltage, Current) |
| DCS601-5150-51-R | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-5150-51-R | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-2603-11-L |                   | Transformers, Transducers (Voltage, Current) |
| DCS601-2650-11-L | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-2650-11-L | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-2603-11-R |                   | Transformers, Transducers (Voltage, Current) |
| DCS601-2650-11-R | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-2650-11-R | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-3303-11-L |                   | Transformers, Transducers (Voltage, Current) |
| DCS601-3200-11-L | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-3200-11-L | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-3303-11-R |                   | Transformers, Transducers (Voltage, Current) |
| DCS601-3200-11-R | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS601-3200-11-R | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-2050-61-R | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-2050-61-R | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-2050-61-L | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-2050-61-L | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-2050-71-R | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-2050-71-R | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |

| Product          | Category          | Drive Part Category                          |
|------------------|-------------------|----------------------------------------------|
| DCS602-2050-71-L | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-2050-71-L | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-2050-81-R | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-2050-81-R | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-2050-81-L | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-2050-81-L | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-2053-91-L |                   | Transformers, Transducers (Voltage, Current) |
| DCS602-2050-91-L | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-2050-91-L | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-2053-91-R |                   | Transformers, Transducers (Voltage, Current) |
| DCS602-2050-91-R | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-2050-91-R | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-2500-41-R | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-2500-41-R | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-2500-41-L | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-2500-41-L | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-2500-51-R | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-2500-51-R | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-2500-51-L | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-2500-51-L | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-2500-61-R | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-2500-61-R | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-2500-61-L | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-2500-61-L | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-2500-71-R | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-2500-71-R | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-2500-71-L | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-2500-71-L | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-2603-91-L |                   | Transformers, Transducers (Voltage, Current) |
| DCS602-2650-91-L | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-2650-91-L | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-2603-91-R |                   | Transformers, Transducers (Voltage, Current) |

| Product          | Category          | Drive Part Category                          |
|------------------|-------------------|----------------------------------------------|
| DCS602-2650-91-R | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-2650-91-R | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-3200-81-R | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-3200-81-R | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-3200-81-L | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-3200-81-L | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-3200-91-R | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-3200-91-R | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-3200-91-L | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-3200-91-L | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-3303-41-L |                   | Transformers, Transducers (Voltage, Current) |
| DCS602-3300-41-L | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-3300-41-L | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-3303-41-R |                   | Transformers, Transducers (Voltage, Current) |
| DCS602-3300-41-R | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-3300-41-R | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-3303-51-L |                   | Transformers, Transducers (Voltage, Current) |
| DCS602-3300-51-L | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-3300-51-L | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-3303-51-R |                   | Transformers, Transducers (Voltage, Current) |
| DCS602-3300-51-R | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-3300-51-R | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-3303-61-L |                   | Transformers, Transducers (Voltage, Current) |
| DCS602-3300-61-L | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-3300-61-L | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-3303-61-R |                   | Transformers, Transducers (Voltage, Current) |
| DCS602-3300-61-R | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-3300-61-R | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-3303-71-L |                   | Transformers, Transducers (Voltage, Current) |
| DCS602-3300-71-L | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-3300-71-L | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-3303-71-R |                   | Transformers, Transducers (Voltage, Current) |

| Product          | Category          | Drive Part Category                          |
|------------------|-------------------|----------------------------------------------|
| DCS602-3300-71-R | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-3300-71-R | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-3303-81-L |                   | Transformers, Transducers (Voltage, Current) |
| DCS602-3303-81-R |                   | Transformers, Transducers (Voltage, Current) |
| DCS602-3303-91-L |                   | Transformers, Transducers (Voltage, Current) |
| DCS602-3303-91-R |                   | Transformers, Transducers (Voltage, Current) |
| DCS602-4003-41-L |                   | Transformers, Transducers (Voltage, Current) |
| DCS602-4000-41-L | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-4000-41-L | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-4003-41-R |                   | Transformers, Transducers (Voltage, Current) |
| DCS602-4000-41-R | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-4000-41-R | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-4003-51-L |                   | Transformers, Transducers (Voltage, Current) |
| DCS602-4000-51-L | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-4000-51-L | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-4003-51-R |                   | Transformers, Transducers (Voltage, Current) |
| DCS602-4000-51-R | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-4000-51-R | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-4003-61-L |                   | Transformers, Transducers (Voltage, Current) |
| DCS602-4000-61-L | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-4000-61-L | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-4003-61-R |                   | Transformers, Transducers (Voltage, Current) |
| DCS602-4000-61-R | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-4000-61-R | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-4003-71-L |                   | Transformers, Transducers (Voltage, Current) |
| DCS602-4000-71-L | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-4000-71-L | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-4003-71-R |                   | Transformers, Transducers (Voltage, Current) |
| DCS602-4000-71-R | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-4000-71-R | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-4003-81-L |                   | Transformers, Transducers (Voltage, Current) |
| DCS602-4000-81-L | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |

| Product          | Category          | Drive Part Category                          |
|------------------|-------------------|----------------------------------------------|
| DCS602-4000-81-L | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-4003-81-R |                   | Transformers, Transducers (Voltage, Current) |
| DCS602-4000-81-R | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-4000-81-R | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-4003-91-L |                   | Transformers, Transducers (Voltage, Current) |
| DCS602-4000-91-L | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-4000-91-L | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-4003-91-R |                   | Transformers, Transducers (Voltage, Current) |
| DCS602-4000-91-R | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-4000-91-R | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-4803-61-L |                   | Transformers, Transducers (Voltage, Current) |
| DCS602-4750-61-L | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-4750-61-L | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-4803-61-R |                   | Transformers, Transducers (Voltage, Current) |
| DCS602-4750-61-R | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-4750-61-R | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-4803-71-L |                   | Transformers, Transducers (Voltage, Current) |
| DCS602-4750-71-L | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-4750-71-L | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-4803-71-R |                   | Transformers, Transducers (Voltage, Current) |
| DCS602-4750-71-R | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-4750-71-R | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-4803-81-L |                   | Transformers, Transducers (Voltage, Current) |
| DCS602-4750-81-L | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-4750-81-L | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-4803-81-R |                   | Transformers, Transducers (Voltage, Current) |
| DCS602-4750-81-R | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-4750-81-R | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-5203-41-L |                   | Transformers, Transducers (Voltage, Current) |
| DCS602-5150-41-L | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-5150-41-L | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-5203-41-R |                   | Transformers, Transducers (Voltage, Current) |

| Product          | Category          | Drive Part Category                          |
|------------------|-------------------|----------------------------------------------|
| DCS602-5150-41-R | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-5150-41-R | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-5203-51-L |                   | Transformers, Transducers (Voltage, Current) |
| DCS602-5150-51-L | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-5150-51-L | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-5203-51-R |                   | Transformers, Transducers (Voltage, Current) |
| DCS602-5150-51-R | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-5150-51-R | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-2603-11-L |                   | Transformers, Transducers (Voltage, Current) |
| DCS602-2650-11-L | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-2650-11-L | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-2603-11-R |                   | Transformers, Transducers (Voltage, Current) |
| DCS602-2650-11-R | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-2650-11-R | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-3303-11-L |                   | Transformers, Transducers (Voltage, Current) |
| DCS602-3200-11-L | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-3200-11-L | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-3303-11-R |                   | Transformers, Transducers (Voltage, Current) |
| DCS602-3200-11-R | DCS600 CraneDrive | Transformers, Transducers (Voltage, Current) |
| DCS602-3200-11-R | DCS600 MultiDrive | Transformers, Transducers (Voltage, Current) |
| DCS501B2050-61-R | DCS500B           | Transformers, Transducers (Voltage, Current) |
| DCS501B2050-61-L | DCS500B           | Transformers, Transducers (Voltage, Current) |
| DCS501B2050-71-R | DCS500B           | Transformers, Transducers (Voltage, Current) |
| DCS501B2050-71-L | DCS500B           | Transformers, Transducers (Voltage, Current) |
| DCS501B2050-81-R | DCS500B           | Transformers, Transducers (Voltage, Current) |
| DCS501B2050-81-L | DCS500B           | Transformers, Transducers (Voltage, Current) |
| DCS501B2053-91-L |                   | Transformers, Transducers (Voltage, Current) |
| DCS501B2050-91-L | DCS500B           | Transformers, Transducers (Voltage, Current) |
| DCS501B2053-91-R |                   | Transformers, Transducers (Voltage, Current) |
| DCS501B2050-91-R | DCS500B           | Transformers, Transducers (Voltage, Current) |
| DCS501B2500-41-R | DCS500B           | Transformers, Transducers (Voltage, Current) |
| DCS501B2500-41-L | DCS500B           | Transformers, Transducers (Voltage, Current) |

| Product          | Category | Drive Part Category                          |
|------------------|----------|----------------------------------------------|
| DCS501B2500-51-R | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS501B2500-51-L | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS501B2500-61-R | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS501B2500-61-L | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS501B2500-71-R | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS501B2500-71-L | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS501B2603-91-L |          | Transformers, Transducers (Voltage, Current) |
| DCS501B2650-91-L | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS501B2603-91-R |          | Transformers, Transducers (Voltage, Current) |
| DCS501B2650-91-R | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS501B3200-81-R | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS501B3200-81-L | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS501B3200-91-R | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS501B3200-91-L | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS501B3303-41-L |          | Transformers, Transducers (Voltage, Current) |
| DCS501B3300-41-L | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS501B3303-41-R |          | Transformers, Transducers (Voltage, Current) |
| DCS501B3300-41-R | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS501B3303-51-L |          | Transformers, Transducers (Voltage, Current) |
| DCS501B3300-51-L | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS501B3303-51-R |          | Transformers, Transducers (Voltage, Current) |
| DCS501B3300-51-R | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS501B3303-61-L |          | Transformers, Transducers (Voltage, Current) |
| DCS501B3300-61-L | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS501B3303-61-R |          | Transformers, Transducers (Voltage, Current) |
| DCS501B3300-61-R | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS501B3303-71-L |          | Transformers, Transducers (Voltage, Current) |
| DCS501B3300-71-L | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS501B3303-71-R |          | Transformers, Transducers (Voltage, Current) |
| DCS501B3300-71-R | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS501B3303-81-L |          | Transformers, Transducers (Voltage, Current) |
| DCS501B3303-81-R |          | Transformers, Transducers (Voltage, Current) |

| Product          | Category | Drive Part Category                          |
|------------------|----------|----------------------------------------------|
| DCS501B3303-91-L |          | Transformers, Transducers (Voltage, Current) |
| DCS501B3303-91-R |          | Transformers, Transducers (Voltage, Current) |
| DCS501B4003-41-L |          | Transformers, Transducers (Voltage, Current) |
| DCS501B4000-41-L | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS501B4003-41-R |          | Transformers, Transducers (Voltage, Current) |
| DCS501B4000-41-R | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS501B4003-51-L |          | Transformers, Transducers (Voltage, Current) |
| DCS501B4000-51-L | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS501B4003-51-R |          | Transformers, Transducers (Voltage, Current) |
| DCS501B4000-51-R | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS501B4003-61-L |          | Transformers, Transducers (Voltage, Current) |
| DCS501B4000-61-L | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS501B4003-61-R |          | Transformers, Transducers (Voltage, Current) |
| DCS501B4000-61-R | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS501B4003-71-L |          | Transformers, Transducers (Voltage, Current) |
| DCS501B4000-71-L | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS501B4003-71-R |          | Transformers, Transducers (Voltage, Current) |
| DCS501B4000-71-R | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS501B4003-81-L |          | Transformers, Transducers (Voltage, Current) |
| DCS501B4000-81-L | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS501B4003-81-R |          | Transformers, Transducers (Voltage, Current) |
| DCS501B4000-81-R | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS501B4003-91-L |          | Transformers, Transducers (Voltage, Current) |
| DCS501B4000-91-L | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS501B4003-91-R |          | Transformers, Transducers (Voltage, Current) |
| DCS501B4000-91-R | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS501B4803-61-L |          | Transformers, Transducers (Voltage, Current) |
| DCS501B4750-61-L | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS501B4803-61-R |          | Transformers, Transducers (Voltage, Current) |
| DCS501B4750-61-R | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS501B4803-71-L |          | Transformers, Transducers (Voltage, Current) |
| DCS501B4750-71-L | DCS500B  | Transformers, Transducers (Voltage, Current) |

| Product          | Category | Drive Part Category                          |
|------------------|----------|----------------------------------------------|
| DCS501B4803-71-R |          | Transformers, Transducers (Voltage, Current) |
| DCS501B4750-71-R | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS501B4803-81-L |          | Transformers, Transducers (Voltage, Current) |
| DCS501B4750-81-L | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS501B4803-81-R |          | Transformers, Transducers (Voltage, Current) |
| DCS501B4750-81-R | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS501B5203-41-L |          | Transformers, Transducers (Voltage, Current) |
| DCS501B5150-41-L | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS501B5203-41-R |          | Transformers, Transducers (Voltage, Current) |
| DCS501B5150-41-R | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS501B5203-51-L |          | Transformers, Transducers (Voltage, Current) |
| DCS501B5150-51-L | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS501B5203-51-R |          | Transformers, Transducers (Voltage, Current) |
| DCS501B5150-51-R | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS501B2603-11-L |          | Transformers, Transducers (Voltage, Current) |
| DCS501B2650-11-L | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS501B2603-11-R |          | Transformers, Transducers (Voltage, Current) |
| DCS501B2650-11-R | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS501B3303-11-L |          | Transformers, Transducers (Voltage, Current) |
| DCS501B3200-11-L | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS501B3303-11-R |          | Transformers, Transducers (Voltage, Current) |
| DCS501B3200-11-R | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS502B2050-61-R | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS502B2050-61-L | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS502B2050-71-R | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS502B2050-71-L | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS502B2050-81-R | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS502B2050-81-L | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS502B2053-91-L |          | Transformers, Transducers (Voltage, Current) |
| DCS502B2050-91-L | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS502B2053-91-R |          | Transformers, Transducers (Voltage, Current) |
| DCS502B2050-91-R | DCS500B  | Transformers, Transducers (Voltage, Current) |

| Product          | Category | Drive Part Category                          |
|------------------|----------|----------------------------------------------|
| DCS502B2500-41-R | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS502B2500-41-L | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS502B2500-51-R | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS502B2500-51-L | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS502B2500-61-R | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS502B2500-61-L | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS502B2500-71-R | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS502B2500-71-L | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS502B2603-91-L |          | Transformers, Transducers (Voltage, Current) |
| DCS502B2650-91-L | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS502B2603-91-R |          | Transformers, Transducers (Voltage, Current) |
| DCS502B2650-91-R | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS502B3200-81-R | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS502B3200-81-L | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS502B3200-91-R | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS502B3200-91-L | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS502B3303-41-L |          | Transformers, Transducers (Voltage, Current) |
| DCS502B3300-41-L | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS502B3303-41-R |          | Transformers, Transducers (Voltage, Current) |
| DCS502B3300-41-R | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS502B3303-51-L |          | Transformers, Transducers (Voltage, Current) |
| DCS502B3300-51-L | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS502B3303-51-R |          | Transformers, Transducers (Voltage, Current) |
| DCS502B3300-51-R | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS502B3303-61-L |          | Transformers, Transducers (Voltage, Current) |
| DCS502B3300-61-L | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS502B3303-61-R |          | Transformers, Transducers (Voltage, Current) |
| DCS502B3300-61-R | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS502B3303-71-L |          | Transformers, Transducers (Voltage, Current) |
| DCS502B3300-71-L | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS502B3303-71-R |          | Transformers, Transducers (Voltage, Current) |
| DCS502B3300-71-R | DCS500B  | Transformers, Transducers (Voltage, Current) |

| Product          | Category | Drive Part Category                          |
|------------------|----------|----------------------------------------------|
| DCS502B3303-81-L |          | Transformers, Transducers (Voltage, Current) |
| DCS502B3303-81-R |          | Transformers, Transducers (Voltage, Current) |
| DCS502B3303-91-L |          | Transformers, Transducers (Voltage, Current) |
| DCS502B3303-91-R |          | Transformers, Transducers (Voltage, Current) |
| DCS502B4003-41-L |          | Transformers, Transducers (Voltage, Current) |
| DCS502B4000-41-L | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS502B4003-41-R |          | Transformers, Transducers (Voltage, Current) |
| DCS502B4000-41-R | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS502B4003-51-L |          | Transformers, Transducers (Voltage, Current) |
| DCS502B4000-51-L | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS502B4003-51-R |          | Transformers, Transducers (Voltage, Current) |
| DCS502B4000-51-R | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS502B4003-61-L |          | Transformers, Transducers (Voltage, Current) |
| DCS502B4000-61-L | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS502B4003-61-R |          | Transformers, Transducers (Voltage, Current) |
| DCS502B4000-61-R | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS502B4003-71-L |          | Transformers, Transducers (Voltage, Current) |
| DCS502B4000-71-L | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS502B4003-71-R |          | Transformers, Transducers (Voltage, Current) |
| DCS502B4000-71-R | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS502B4003-81-L |          | Transformers, Transducers (Voltage, Current) |
| DCS502B4000-81-L | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS502B4003-81-R |          | Transformers, Transducers (Voltage, Current) |
| DCS502B4000-81-R | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS502B4003-91-L |          | Transformers, Transducers (Voltage, Current) |
| DCS502B4000-91-L | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS502B4003-91-R |          | Transformers, Transducers (Voltage, Current) |
| DCS502B4000-91-R | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS502B4803-61-L |          | Transformers, Transducers (Voltage, Current) |
| DCS502B4750-61-L | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS502B4803-61-R |          | Transformers, Transducers (Voltage, Current) |
| DCS502B4750-61-R | DCS500B  | Transformers, Transducers (Voltage, Current) |

| Product             | Category | Drive Part Category                          |
|---------------------|----------|----------------------------------------------|
| DCS502B4803-71-L    |          | Transformers, Transducers (Voltage, Current) |
| DCS502B4750-71-L    | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS502B4803-71-R    |          | Transformers, Transducers (Voltage, Current) |
| DCS502B4750-71-R    | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS502B4803-81-L    |          | Transformers, Transducers (Voltage, Current) |
| DCS502B4750-81-L    | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS502B4803-81-R    |          | Transformers, Transducers (Voltage, Current) |
| DCS502B4750-81-R    | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS502B5203-41-L    |          | Transformers, Transducers (Voltage, Current) |
| DCS502B5150-41-L    | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS502B5203-41-R    |          | Transformers, Transducers (Voltage, Current) |
| DCS502B5150-41-R    | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS502B5203-51-L    |          | Transformers, Transducers (Voltage, Current) |
| DCS502B5150-51-L    | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS502B5203-51-R    |          | Transformers, Transducers (Voltage, Current) |
| DCS502B5150-51-R    | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS502B2603-11-L    |          | Transformers, Transducers (Voltage, Current) |
| DCS502B2650-11-L    | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS502B2603-11-R    |          | Transformers, Transducers (Voltage, Current) |
| DCS502B2650-11-R    | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS502B3303-11-L    |          | Transformers, Transducers (Voltage, Current) |
| DCS502B3200-11-L    | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS502B3303-11-R    |          | Transformers, Transducers (Voltage, Current) |
| DCS502B3200-11-R    | DCS500B  | Transformers, Transducers (Voltage, Current) |
| DCS800-S01-2050-10R | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S01-2600-10R | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S01-3300-04R | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S01-3300-05R | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S01-3300-06R | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S01-3300-07R | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S01-3300-08R | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S01-3300-10R | DCS800-S | Transformers, Transducers (Voltage, Current) |

| Product             | Category | Drive Part Category                          |
|---------------------|----------|----------------------------------------------|
| DCS800-S01-4000-04R | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S01-4000-05R | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S01-4000-06R | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S01-4000-07R | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S01-4000-08R | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S01-4000-10R | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S01-4800-06R | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S01-4800-07R | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S01-4800-08R | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S01-5200-04R | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S01-5200-05R | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S02-2050-10R | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S02-2600-10R | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S02-3300-04R | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S02-3300-05R | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S02-3300-06R | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S02-3300-07R | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S02-3300-08R | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S02-3300-10R | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S02-4000-04R | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S02-4000-05R | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S02-4000-06R | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S02-4000-07R | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S02-4000-08R | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S02-4000-10R | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S02-4800-06R | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S02-4800-07R | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S02-4800-08R | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S02-5200-04R | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S02-5200-05R | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S01-2600-10L | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S01-3300-04L | DCS800-S | Transformers, Transducers (Voltage, Current) |

| Product             | Category | Drive Part Category                          |
|---------------------|----------|----------------------------------------------|
| DCS800-S01-3300-05L | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S01-3300-06L | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S01-3300-07L | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S01-3300-08L | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S01-3300-10L | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S01-4000-04L | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S01-4000-05L | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S01-4000-06L | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S01-4000-07L | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S01-4000-08L | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S01-4000-10L | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S01-4800-06L | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S01-4800-07L | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S01-4800-08L | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S01-5200-04L | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S01-5200-05L | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S02-2050-10L |          | Transformers, Transducers (Voltage, Current) |
| DCS800-S02-2600-10L | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S02-3300-04L | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S02-3300-05L | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S02-3300-06L | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S02-3300-07L | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S02-3300-08L | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S02-3300-10L | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S02-4000-04L | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S02-4000-05L | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S02-4000-06L | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S02-4000-07L | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S02-4000-08L | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S02-4000-10L | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S02-4800-06L | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S02-4800-07L | DCS800-S | Transformers, Transducers (Voltage, Current) |

| Product              | Category | Drive Part Category                          |
|----------------------|----------|----------------------------------------------|
| DCS800-S02-4800-08L  | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S02-5200-04L  | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S02-5200-05L  | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S01-2050-10-b | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S01-2600-10-b | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S01-3300-04-b | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S01-3300-05-b | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S01-3300-06-b | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S01-3300-07-b | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S01-3300-08-b | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S01-3300-10-b | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S01-4000-04-b | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S01-4000-05-b | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S01-4000-06-b | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S01-4000-07-b | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S01-4000-08-b | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S01-4000-10-b | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S01-4800-06-b | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S01-4800-07-b | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S01-4800-08-b | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S01-5200-04-b | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S01-5200-05-b | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S02-2050-10-b | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S02-2600-10-b | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S02-3300-04-b | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S02-3300-05-b | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S02-3300-06-b | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S02-3300-07-b | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S02-3300-08-b | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S02-3300-10-b | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S02-4000-04-b | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S02-4000-05-b | DCS800-S | Transformers, Transducers (Voltage, Current) |

| Product              | Category | Drive Part Category                          |
|----------------------|----------|----------------------------------------------|
| DCS800-S02-4000-06-b | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S02-4000-07-b | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S02-4000-08-b | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S02-4000-10-b | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S02-4800-06-b | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S02-4800-07-b | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S02-4800-08-b | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S02-5200-04-b | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS800-S02-5200-05-b | DCS800-S | Transformers, Transducers (Voltage, Current) |
| DCS880-S01-2050-10X0 | DCS880-S | Transformers, Transducers (Voltage, Current) |
| DCS880-S01-2600-10X0 | DCS880-S | Transformers, Transducers (Voltage, Current) |
| DCS880-S01-2600-12X0 | DCS880-S | Transformers, Transducers (Voltage, Current) |
| DCS880-S01-3300-04X0 | DCS880-S | Transformers, Transducers (Voltage, Current) |
| DCS880-S01-3300-05X0 | DCS880-S | Transformers, Transducers (Voltage, Current) |
| DCS880-S01-3300-06X0 | DCS880-S | Transformers, Transducers (Voltage, Current) |
| DCS880-S01-3300-07X0 | DCS880-S | Transformers, Transducers (Voltage, Current) |
| DCS880-S01-3300-08X0 | DCS880-S | Transformers, Transducers (Voltage, Current) |
| DCS880-S01-3300-10X0 | DCS880-S | Transformers, Transducers (Voltage, Current) |
| DCS880-S01-3300-12X0 | DCS880-S | Transformers, Transducers (Voltage, Current) |
| DCS880-S01-4000-04X0 | DCS880-S | Transformers, Transducers (Voltage, Current) |
| DCS880-S01-4000-05X0 | DCS880-S | Transformers, Transducers (Voltage, Current) |
| DCS880-S01-4000-06X0 | DCS880-S | Transformers, Transducers (Voltage, Current) |
| DCS880-S01-4000-07X0 | DCS880-S | Transformers, Transducers (Voltage, Current) |
| DCS880-S01-4000-08X0 | DCS880-S | Transformers, Transducers (Voltage, Current) |
| DCS880-S01-4000-10X0 | DCS880-S | Transformers, Transducers (Voltage, Current) |
| DCS880-S01-4000-12X0 | DCS880-S | Transformers, Transducers (Voltage, Current) |
| DCS880-S01-4800-06X0 | DCS880-S | Transformers, Transducers (Voltage, Current) |
| DCS880-S01-4800-07X0 | DCS880-S | Transformers, Transducers (Voltage, Current) |
| DCS880-S01-4800-08X0 | DCS880-S | Transformers, Transducers (Voltage, Current) |
| DCS880-S01-5200-04X0 | DCS880-S | Transformers, Transducers (Voltage, Current) |
| DCS880-S01-5200-05X0 | DCS880-S | Transformers, Transducers (Voltage, Current) |
| DCS880-S02-2050-10X0 | DCS880-S | Transformers, Transducers (Voltage, Current) |

| Product              | Category | Drive Part Category                          |
|----------------------|----------|----------------------------------------------|
| DCS880-S02-2600-10X0 | DCS880-S | Transformers, Transducers (Voltage, Current) |
| DCS880-S02-2600-12X0 | DCS880-S | Transformers, Transducers (Voltage, Current) |
| DCS880-S02-3300-04X0 | DCS880-S | Transformers, Transducers (Voltage, Current) |
| DCS880-S02-3300-05X0 | DCS880-S | Transformers, Transducers (Voltage, Current) |
| DCS880-S02-3300-06X0 | DCS880-S | Transformers, Transducers (Voltage, Current) |
| DCS880-S02-3300-07X0 | DCS880-S | Transformers, Transducers (Voltage, Current) |
| DCS880-S02-3300-08X0 | DCS880-S | Transformers, Transducers (Voltage, Current) |
| DCS880-S02-3300-10X0 | DCS880-S | Transformers, Transducers (Voltage, Current) |
| DCS880-S02-3300-12X0 | DCS880-S | Transformers, Transducers (Voltage, Current) |
| DCS880-S02-4000-04X0 | DCS880-S | Transformers, Transducers (Voltage, Current) |
| DCS880-S02-4000-05X0 | DCS880-S | Transformers, Transducers (Voltage, Current) |
| DCS880-S02-4000-06X0 | DCS880-S | Transformers, Transducers (Voltage, Current) |
| DCS880-S02-4000-07X0 | DCS880-S | Transformers, Transducers (Voltage, Current) |
| DCS880-S02-4000-08X0 | DCS880-S | Transformers, Transducers (Voltage, Current) |
| DCS880-S02-4000-10X0 | DCS880-S | Transformers, Transducers (Voltage, Current) |
| DCS880-S02-4000-12X0 | DCS880-S | Transformers, Transducers (Voltage, Current) |
| DCS880-S02-4800-06X0 | DCS880-S | Transformers, Transducers (Voltage, Current) |
| DCS880-S02-4800-07X0 | DCS880-S | Transformers, Transducers (Voltage, Current) |
| DCS880-S02-4800-08X0 | DCS880-S | Transformers, Transducers (Voltage, Current) |
| DCS880-S02-5200-04X0 | DCS880-S | Transformers, Transducers (Voltage, Current) |
| DCS880-S02-5200-05X0 | DCS880-S | Transformers, Transducers (Voltage, Current) |

## Categories

Drives → DC Drives → Industrial Drives → Modules → DCS800-S

Drives → DC Drives → Industrial Drives → Modules → DCS880-S

Drives → DC Drives → Legacy DC Drives → DCS500B

Drives → DC Drives → Legacy DC Drives → DCS600 CraneDrive

Drives → DC Drives → Legacy DC Drives → DCS600 MultiDrive

