



PRODUCT-DETAILS

3ADT751010P0003

CURRENT-TRANS.-3KA; CURRENT TRANSFORMER 3KA, 2500 : 1

General Information

Product ID	3ADT751010P0003
ABB Type Designation	CURRENT-TRANS.-3KA
Catalog Description	CURRENT-TRANS.-3KA; CURRENT TRANSFORMER 3KA, 2500 : 1

Ordering

Customs Tariff Number	85043129
Replaced Product ID (OLD)	3ADT751010P0001
Quote Only	No
Made To Order	No
Part Type	New
Selling Unit of Measure	piece
Minimum Order Quantity	1 piece
Order Multiple	1 piece

Dimensions

Product Net Weight	1.626 kg
--------------------	----------

Additional Information

Product Name	CURRENT TRANSFORMER 3KA, 2500 : 1
--------------	-----------------------------------

Where Used (as a spare part for "Products")

Identifier	Description	Quantity	Unit Of Measure
DCS800-S01-0900-06	No Description Available	1	piece
DCS800-S01-0900-07	No Description Available	1	piece
DCS800-S01-1200-04	No Description Available	1	piece
DCS800-S01-1200-05	No Description Available	1	piece
DCS800-S01-1500-04	No Description Available	1	piece

[illegible]

[illegible]

DCS880-S01-3000-05XA	No Description Available	1	piece
DCS880-S01-3000-06XA	No Description Available	1	piece
DCS880-S01-3000-07XA	No Description Available	1	piece
DCS880-S01-3000-08XA	No Description Available	1	piece
DCS880-S02-1900-08XA	No Description Available	1	piece
DCS880-S02-2050-05XA	No Description Available	1	piece
DCS880-S02-2050-06XA	No Description Available	1	piece
DCS880-S02-2050-07XA	No Description Available	1	piece
DCS880-S02-2500-04XA	No Description Available	1	piece
DCS880-S02-2500-05XA	No Description Available	1	piece
DCS880-S02-2500-06XA	No Description Available	1	piece
DCS880-S02-2500-07XA	No Description Available	1	piece
DCS880-S02-2500-08XA	No Description Available	1	piece
DCS880-S02-3000-04XA	No Description Available	1	piece
DCS880-S02-3000-05XA	No Description Available	1	piece
DCS880-S02-3000-06XA	No Description Available	1	piece
DCS880-S02-3000-07XA	No Description Available	1	piece
DCS880-S02-3000-08XA	No Description Available	1	piece
DCT880-W03-1300-04	No Description Available	1	piece
DCT880-W03-1300-05	No Description Available	1	piece
DCT880-W03-1300-07	No Description Available	1	piece
DCT880-W03-1750-04	No Description Available	1	piece
DCT880-W03-1750-05	No Description Available	1	piece
DCT880-W03-1750-07	No Description Available	1	piece

Product specific part data

Product	Category	Drive Part Category
DCS800-S01-0900-06	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-0900-07	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-1200-04	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-1200-05	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-1500-04	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-1500-05	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-1500-06	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-1500-07	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-1900-08	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-2000-04	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-2000-05	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-2000-06	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-2000-07	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-2050-05	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-2050-06	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-2050-07	DCS800-S	Transformers, Transducers (Voltage, Current)

Product	Category	Drive Part Category
DCS800-S01-2500-04	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-2500-05	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-2500-06	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-2500-07	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-2500-08	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-3000-04	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-3000-05	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-3000-06	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-3000-07	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-3000-08	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-0900-06	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-0900-07	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-1200-04	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-1200-05	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-1500-04	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-1500-05	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-1500-06	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-1500-07	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-1900-08	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-2000-04	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-2000-05	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-2050-05	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-2050-06	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-2050-07	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-2500-04	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-2500-05	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-2500-06	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-2500-07	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-2500-08	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-3000-04	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-3000-05	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-3000-06	DCS800-S	Transformers, Transducers (Voltage, Current)

Product	Category	Drive Part Category
DCS800-S02-3000-07	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-3000-08	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-0900-06X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-0900-07X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-0900-06X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-0900-07X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-1200-04X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-1200-05X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-1200-04X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-1200-05X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-1500-04X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-1500-05X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-1500-06X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-1500-07X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-1500-04X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-1500-05X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-1500-06X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-1500-07X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-2000-04X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-2000-05X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-2000-06X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-2000-07X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-2000-04X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-2000-05X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-0900-06a	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-0900-06-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-0900-07a	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-0900-07-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-1200-04a	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-1200-04-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-1200-05a	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-1200-05-b	DCS800-S	Transformers, Transducers (Voltage, Current)

Product	Category	Drive Part Category
DCS800-S01-1500-04-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-1500-05-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-1500-06-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-1500-07-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-1900-08a	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-1900-08-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-2000-04-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-2000-05-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-2000-06-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-2000-07-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-2050-05a	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-2050-05-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-2050-06a	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-2050-06-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-2050-07a	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-2050-07-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-2500-04-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-2500-05-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-2500-06-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-2500-07-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-2500-08-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-3000-04-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-3000-05-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-3000-06-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-3000-07-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-3000-08-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-0900-06a	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-0900-06-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-0900-07a	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-0900-07-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-1200-04a	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-1200-04-b	DCS800-S	Transformers, Transducers (Voltage, Current)

Product	Category	Drive Part Category
DCS800-S02-1200-05a	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-1200-05-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-1500-04-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-1500-05-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-1500-06-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-1500-07-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-1900-08a	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-1900-08-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-2000-04-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-2000-05-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-2050-05a	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-2050-05-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-2050-06a	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-2050-06-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-2050-07a	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-2050-07-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-2500-04-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-2500-05-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-2500-06-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-2500-07-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-2500-08-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-3000-04-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-3000-05-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-3000-06-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-3000-07-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-3000-08-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-1900-08X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-2050-05X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-2050-06X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-2050-07X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-2500-04X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-2500-05X0	DCS880-S	Transformers, Transducers (Voltage, Current)

Product	Category	Drive Part Category
DCS880-S01-2500-06X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-2500-07X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-2500-08X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-3000-04X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-3000-05X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-3000-06X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-3000-07X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-3000-08X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-1900-08X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-2050-05X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-2050-06X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-2050-07X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-2500-04X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-2500-05X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-2500-06X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-2500-07X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-2500-08X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-3000-04X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-3000-05X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-3000-06X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-3000-07X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-3000-08X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-1900-08XA	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-2050-05XA	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-2050-06XA	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-2050-07XA	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-2500-04XA	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-2500-05XA	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-2500-06XA	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-2500-07XA	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-2500-08XA	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-3000-04XA	DCS880-S	Transformers, Transducers (Voltage, Current)

Product	Category	Drive Part Category
DCS880-S01-3000-05XA	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-3000-06XA	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-3000-07XA	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-3000-08XA	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-1900-08XA	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-2050-05XA	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-2050-06XA	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-2050-07XA	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-2500-04XA	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-2500-05XA	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-2500-06XA	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-2500-07XA	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-2500-08XA	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-3000-04XA	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-3000-05XA	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-3000-06XA	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-3000-07XA	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-3000-08XA	DCS880-S	Transformers, Transducers (Voltage, Current)
DCT880-W03-1300-04	DCT880-W	Transformers, Transducers (Voltage, Current)
DCT880-W03-1300-05	DCT880-W	Transformers, Transducers (Voltage, Current)
DCT880-W03-1300-07	DCT880-W	Transformers, Transducers (Voltage, Current)
DCT880-W03-1750-04	DCT880-W	Transformers, Transducers (Voltage, Current)
DCT880-W03-1750-05	DCT880-W	Transformers, Transducers (Voltage, Current)
DCT880-W03-1750-07	DCT880-W	Transformers, Transducers (Voltage, Current)

Categories

Drives → DC Drives → Industrial Drives → Modules → DCS800-S

Drives → DC Drives → Industrial Drives → Modules → DCS880-S

Drives → DC Drives → Industrial Drives → Modules → DCT880-W

Drives → Services → Spares and Consumables → Parts